

BASIN AND KITCHEN MIXER INSTALLATION

INSTALLATION TO SUIT :

A67.02.LH, A67.02.V2.LH,
A67.03.LH, A67.03.V2.LH,
A67.08.LH, A67.08.V2.LH

A68.02.KN, A67.02.V2.KN,
A68.03.KN, A67.03.V2.KN,
A68.08.KN, A67.08.V2.KN

A69.02, A69.02.V2,
A69.03, A69.03.V2,
A69.08, A69.08.V2

- Tapware to be installed by a licenced plumber in accordance with AS/NZS 3500:2021
- Recommended working water pressure 150 - 500kPa
- This tap is suitable for high pressure applications where both hot & cold water supply pressures are at 150kpa or above
- Maximum water temperature is 65 deg C
- Flush out pipework prior to new installation
- Please ensure any flow controller incorporated in the outlet be tightened to prevent removal by hand.
- After completing the installation check function of tapware and ensure no water leaks.
- WARRANTY: Please refer to the full warranty statement before installing at <https://astrawalker.com.au/certification-warranty/>

1. Place the tap body onto the sink hole provision making sure first that the flexible connectors are firmly tightened into base of the body
2. Fit washer and brass fixing nut onto thread assembly. Tighten using tool provided.
3. Connect the hot & cold water supplies to isolating stop cocks.

