



BASIN MIXER INSTALLATION

INSTALLATION TO SUIT :

A51.03,	A51.03.V2	
A51.04,	A51.04.V2	A51.04.V3
A51.30,	A51.03.V2	
A51.33,	A51.33.V2	

1. Water inlet temperature not to exceed 75 degrees C & water pressure not to exceed 500kpa. Recommended working water pressure 150 - 500kPa.
2. This tap is suitable for high pressure applications where both hot & cold water supply pressures are at 150kpa or above
3. Flush out pipe work prior to connecting the new mixer
4. Place the tap body & dress ring into the sink hole making sure first that the flexible connectors are firmly tightened into base of the body
5. Fit washer and brass spacer onto threaded assembly
6. Connect the flexible pull-out hose by tightening the adapting nipple making sure first to insert the rubber seal
7. Connect the hot & cold water supplies to isolating stop cocks.
8. Test for leaks as per AS/NZ 3500



NOTE : The installation of this product must comply with the Australian Plumbing Installation code AS 3500.